

UL NURSE-CALL PATIENT STATIONS

APPLICATION

The IR-151B (IR151B) or IR-152B (IR152B) Patient Station provides for efficient use of the nursing staff by permitting fast and reliable communication between staff and patient. Calling the nurse is accomplished by pressing the call button on the end of a 6' or 10' long call cord.

A non-resettable call is registered if the call cord is accidentally removed from its jack.

Call-placed assurance and intercom operation are indicated by solid-state LEDs. The speaker/microphone is sensitive enough to assure clear conversation, even with weak patients. A "reset" button is provided on the durable, flame-retardant (UL® 94V-0) plastic panel.

FEATURES

- UL® 1069 Listed
- Push button calling
- May be used as a retrofit for the IR-151N or IR-152N station with IH-106N backbox; requires two CL207 mounting adapters.
- Call-placed indicator
- Reset button
- Sensitive speaker/microphone
- Attractive and durable flame-retardant (UL® 94V-0) plastic panel

SPECIFICATIONS

Dimensions: Height: 4.5" (119 mm)
Width: 6.375" (162 mm)
Depth: 1.875" (48 mm)
Projects: 0.5" (12.7 mm) above mounting surface

Speaker: 2.5" × 2.5"

Connections: Plug-in type.

Housing: Steel City #H3BD with Steel City #3GC plaster ring, or TekTone® #IH353 box with IH-352 ring, or equal, or if a smaller box is needed, use ARC-CO #2GB with ARC-CO #3GC ring. Horizontal mount.

REQUIRED COMPONENTS

Tek-CARE® NC-200 or NC-150 Nurse Call System
SF-301 or SF-301/10 Call Cord



IR-151B
Single Patient Station



IR-152B
Dual Patient Station

ARCHITECTS' AND ENGINEERS' SPECIFICATIONS

The patient station shall be TekTone®'s IR-151B, IR-152B or approved equal as supplied by LEE DAN®. The patient station shall provide callplacement indicators, call-cord jacks, combination reset button and in-use indicator, and a 2.5" × 2.5" speaker/microphone with voice response. The patient station electronics shall be mounted on a durable flame-retardant (UL® 94V-0) plastic panel. Connections shall be plug-in connectors.

Removal of the call cords, either accidentally or intentionally, will place a call. The call can only be cancelled after returning the call cord or its equivalent into the call jack.

The IR-151B and IR-152B shall be UL® 1069 Listed.